

Car weight table (HO)

1 ounce + 0.5 ounces per inch

Length is measured in inches, between coupler faces.

Weight is in ounces.

Length	Min weight	Best weight	Max weight
3	2 1/2	2 1/2	3 1/4
3 1/4	2 5/8	2 5/8	3 3/8
3 1/2	2 3/4	2 3/4	3 1/2
3 3/4	2 7/8	2 7/8	3 5/8
4	3	3	3 7/8
4 1/4	3 1/8	3 1/8	4
4 1/2	3 1/4	3 1/4	4 1/8
4 3/4	3 3/8	3 3/8	4 3/8
5	3 1/2	3 1/2	4 1/2
5 1/4	3 5/8	3 5/8	4 5/8
5 1/2	3 3/4	3 3/4	4 7/8
5 3/4	3 7/8	3 7/8	5
6	4	4	5 1/8
6 1/4	4 1/8	4 1/8	5 1/4
6 1/2	4 1/4	4 1/4	5 1/2
6 3/4	4 3/8	4 3/8	5 5/8
7	4 1/2	4 1/2	5 3/4
7 1/4	4 5/8	4 5/8	6
7 1/2	4 3/4	4 3/4	6 1/8
7 3/4	4 7/8	4 7/8	6 1/4
8	5	5	6 1/2
8 1/4	5 1/8	5 1/8	6 5/8
8 1/2	5 1/4	5 1/4	6 3/4
8 3/4	5 3/8	5 3/8	6 7/8
9	5 1/2	5 1/2	7 1/8
9 1/4	5 5/8	5 5/8	7 1/4
9 1/2	5 3/4	5 3/4	7 3/8
9 3/4	5 7/8	5 7/8	7 5/8
10	6	6	7 3/4
10 1/4	6 1/8	6 1/8	7 7/8
10 1/2	6 1/4	6 1/4	8 1/8
10 3/4	6 3/8	6 3/8	8 1/4
11	6 1/2	6 1/2	8 3/8
11 1/4	6 5/8	6 5/8	8 1/2
11 1/2	6 3/4	6 3/4	8 3/4
11 3/4	6 7/8	6 7/8	8 7/8
12	7	7	9

North County Modular Railroad Society

Car weight table (HOn3)

.75 ounce + 0.4 ounces per inch

Length is measured in inches, between coupler faces.

Weight is in ounces.

Length	Min weight	Best weight	Max weight
3	2	2	2 1/2
3 1/4	2 1/8	2 1/8	2 3/4
3 1/2	2 1/4	2 1/4	2 7/8
3 3/4	2 3/8	2 3/8	3
4	2 3/8	2 3/8	3
4 1/4	2 1/2	2 1/2	3 1/4
4 1/2	2 5/8	2 5/8	3 3/8
4 3/4	2 3/4	2 3/4	3 1/2
5	2 7/8	2 7/8	3 5/8
5 1/4	2 7/8	2 7/8	3 5/8
5 1/2	3	3	3 7/8
5 3/4	3 1/8	3 1/8	4
6	3 1/4	3 1/4	4 1/8
6 1/4	3 3/8	3 3/8	4 3/8
6 1/2	3 3/8	3 3/8	4 3/8
6 3/4	3 1/2	3 1/2	4 1/2
7	3 5/8	3 5/8	4 5/8
7 1/4	3 3/4	3 3/4	4 7/8
7 1/2	3 7/8	3 7/8	5
7 3/4	3 7/8	3 7/8	5
8	4	4	5 1/8
8 1/4	4 1/8	4 1/8	5 1/4
8 1/2	4 1/4	4 1/4	5 1/2
8 3/4	4 3/8	4 3/8	5 5/8
9	4 3/8	4 3/8	5 5/8
9 1/4	4 1/2	4 1/2	5 3/4
9 1/2	4 5/8	4 5/8	6
9 3/4	4 3/4	4 3/4	6 1/8
10	4 7/8	4 7/8	6 1/4
10 1/4	4 7/8	4 7/8	6 1/4
10 1/2	5	5	6 1/2
10 3/4	5 1/8	5 1/8	6 5/8
11	5 1/4	5 1/4	6 3/4
11 1/4	5 3/8	5 3/8	6 7/8
11 1/2	5 3/8	5 3/8	6 7/8
11 3/4	5 1/2	5 1/2	7 1/8
12	5 5/8	5 5/8	7 1/4

November, 2001

JCS